

















BIM Helper Tools manuals


 Licenses	 Settings	 Manuals	 Batch print	 Parameters	 Subcategories	 Export library	 Browse families	 Select/manage/import/export	 Configure sheet	 Multi sheets	 Duplicate sheets	 Relocate tags	 Room tags
Software configuration			General tools			Libraries		Elements data	Sheet manipulations			Tags	

Configure sheets


The configure sheets command creates a sheet with views selected by you, placed on the sheet in the order of the selection. It starts placing the views from the upper left part of the sheet, and places from left to right, top to bottom. It is your responsibility to make sure the sheet is big enough to fit the views you want to be placed automatically.



- Press the 'configure sheets' button the dialogue below will appear.



- Select a titleblock on the left hand side of the screen. Select the views that need to be placed on the sheet, in the order of placement. Enter the sheet name as well



- Press "OK". The sheet will now be created.

